

GENOVATION



MacroMasterCPxx User Guide

Revision 1.61
March 2019
Microsoft Windows 32-bit

WARRANTY REPAIR SERVICE AND LICENSE

Genovation, Incorporated ("Genovation") warrants this product to be in good working order and free of defects in materials and workmanship under normal use for a period of one year from the date of purchase. Any implied warranties, including warranties of merchantability and fitness for a particular purpose, are limited in duration to a period of thirty (30) days from date of purchase. Any abuse including opening the case will void the warranty. Your sole remedy and Genovation's entire liability for this product will be repair or replacement as provided for above, or at Genovation's option, the refund of your purchase price. **A RETURN MATERIAL AUTHORIZATION (RMA) number is absolutely required before returning a product. Any shipment received without an RMA will be returned unopened. Please contact Customer Service for instructions before returning any product.** Genovation makes software available and licenses its use to you for world wide for use.

FCC CERTIFICATION

This product has been certified to comply with FCC, EC, TUV and other test standards. See label on the product for confirmation.

FCC CERTIFICATION REQUIRED STATEMENT WARNING:

This equipment has been certified to comply with the limits for a Class B Computing Device, pursuant to Subpart J of Part 15 of the FCC rules. Only peripherals (computer, computer input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this device. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

NOTE: This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for Class B computing devices in accordance with the specifications in Subpart J of part 15 of the FCC Rules, which are designed to provide reasonable protection against such interference in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off or on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antennas
- Relocate the computer with respect to the receiver
- Move the computer away from the receiver
- Plug the computer and receiver into different circuits

If necessary, the user should consult the dealer or an experienced radio/television technician for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to identify and Resolve Radio-TV Interference Problems". This booklet is available from the U.S. Government Printing Office, Washington, DC 20402. (Stock #004-000-00345-4).

TECHNICAL SUPPORT

If you require technical support or if you wish to make suggestions about the product, don't hesitate to contact us. We can be reached Monday through Friday from 7:30 AM to 11:00 AM and from 11:30 AM to 3:30 PM Pacific Time. If the customer support lines are busy or if you are calling after hours, leave a message or send a FAX or E-MAIL and a representative will respond, typically within 24 hours.

VOICE NUMBER:	(949) 833-3355 ext. 115
FAX NUMBER:	(949) 833-0322
EMAIL:	support@genovation.com
WEB:	http://www.genovation.com
FORUM:	http://www.genovation.com/forum/
POST:	Genovation, Inc. 17741 Mitchell North Irvine, CA 92614 USA

CONTENTS

1: Installation and Quick Start Guide6

Before You Begin.....	6
Install Software	7
Install Hardware.....	9
Launch MacroMaster	9
Open File	10
Download File to Keypad	10
Test Keypad.....	12
Restoring Factory Defaults	13
Un-Installing and Re-Installing	14

2: Using MacroMasterCPxx.....15

Running MacroMasterCPxx.....	15
Creating and Saving your first CKD file	17
The Shaded Keys	19
Correcting Mistakes	19
Key Codes	20
Modifiers	21
Inserting Delays	22
Two-Level Programming (Layers).....	24
Copy and Paste Key Macros	25
Keypad Properties	26
Double Size Keys	28
Keycap Labels	28
Key Blockers.....	28
Uninstalling/Removing MacroMaster	29
Customization Is Standard.....	29

3: Advanced Topics30

LED Programming	30
Multimedia and More Keys	31
Macro Modes	32
Modes: Separate Up Codes (v1.13+)	33
Modes: Macro	34
Modes: Literal	35
Mouse Programming	36
Shortcuts.....	42
Rapid Reconfiguration	44
Downloading via PRG/TMode (TMode Models Only)	45
Downloading via Drag n Drop (Flash Drive Models Only).....	46
Reflashing the Firmware	47

4: Technical Specifications	51
A: Appendix.....	53
Scan Code Table	53

1: Installation and Quick Start Guide

Before You Begin

Your ControlPad CP24 or CP48 package should include the following items:

- A Quick Start page
- Product/Installation CD
- ControlPad USB keypad
- Double size keycaps (2) and keycap puller

Features

- Great for any repetitive keystrokes and text
- Saves all your hot-keys, shortcuts and URLs
- Increases speed and productivity while reducing typos
- Adds speed and fun to gaming
- Useful for CAD, online trading, multimedia or any other advanced software
- One-touch control of email, password and login info.

USB CDC serial and true DB-9 RS-232 serial versions of the CP24 and CP48 are available (the CPS24 and CPS48, respectively).

Hardware

The ControlPad keypad is designed to connect to any USB port. Once programmed, the keypad will work with any computer or operating system that supports USB human interface devices.

The ControlPad supports USB boot protocol. This enables the ControlPad to boot a PC and to navigate the BIOS screens.

Software


The MacroMasterCPxx.exe Windows application is a program is designed to work with computers running Microsoft Windows operating systems.

Install Software

Recommended: Check the Genovation website for the latest software.

If you have a Genovation CD, insert the CD into the target computer's CD drive. If the Installation program does not start immediately, navigate to the CD using Explorer and run **Setup.exe**. If you downloaded the software, unzip the file if required and then run **Setup.exe**.

If you see a User Account Control dialog or a warning, such as ¹:




Click on Allow or Yes as necessary. Once Setup begins you should see the following screen:



¹ Genovation installation packages and applications are digitally signed so that you may have peace of mind from malware when installing and using them.

Click on **Next** and choose the path you would like to use for storing your User Data².

Click **Install** to copy the files to your computer from the CD. Click on **Finish** when prompted.



The following files will be installed on your computer:


File	Description
MacroMasterCPxx.pdf	This document.
MacroMasterCPxx.exe	Keypad macro creator/editor (redefinition application).
CPxxLoad.exe	Downloader utility for the keypad.
KeyTest.exe	Keyboard testing application.
Getting Started.pdf	Quick start guide.
\Macro_Files*.ckd	Sample Custom Keypad Definition (.ckd) files.
\Keycap_Labels*.*	Pages for printing custom keycap labels.

The Setup procedure will create the necessary icons on your Start Menu.

² The path for the User Data can be changed at any time using the Location.ini file.

Install Hardware

You may plug in new hardware at any time. If you have not already plugged in your ControlPad keypad, do so now. You should see a few notifications on the bottom right corner of the screen as the automated install proceeds:




Launch MacroMaster

If you have not started your MacroMaster application, do so now. Click on:

Start >> Programs >> Genovation >> MacroMasterCPxx >> MacroMasterCPxx

You should see a screen similar to the following:



Open File


The picture above shows the file DefaultCP24.ckd (or DefaultCP48.ckd) is opened for editing. You should open that file now, following these steps.

- Click on the **Open** button at the top right. The open file dialog appears.
- Click on the file named **DefaultCP24.ckd** or **DefaultCP48.ckd** and then click the **Open** button.

This file contains a few simple keys that can be used to verify the correct operation of your keypad and software installation.


Download File to Keypad

Click on the green arrow of the **Download** button, located near the middle of the toolbar. This will launch the CPxxLoad.exe utility that will in turn send the DefaultCPxx.ckd file to the keypad in standard (legacy) keyboard mode.³




³ There are several download methods available to you.

The standard (legacy) download mode does not utilize the rear panel switch. If you have problems downloading using this mode, then you may see a pop-up like this:



In this case you should use the rear panel switch while downloading instead of the standard mode. Determine which version of keypad you have by looking at the rear panel of the keypad and matching up the diagram on it with one of the diagrams on this pop-up. Click the large button to the right of the diagram that fits your keypad. This will set the mode in CPxxLoad. For example:




You will be guided how to perform the download by CPxxLoad when the time comes. For more information on download modes, see the Advanced Topics section of this manual

Test Keypad

After the download is complete the keypad will reboot. Click on the **Test** button. This will launch the KeyTest.exe utility that can be used to test the operation of your keypad and the correctness of your macros.

Type on the keys of your ControlPad. You should see the data that is programmed into the keypad appearing in the KeyTest panel. Click on **Exit** to close KeyTest when you are finished with it.




Congratulations, your installation is complete!

Restoring Factory Defaults

At any time your ControlPad can be returned to factory defaults. You must use the CPxxLoad.exe PC application to do this.

METHOD 1:

Along the top line of the downloader program you will see a button called **Erase CKD**. With your keypad plugged in and identified by the downloader program, click this button to erase the keypad settings.



METHOD 2:

Though not technically the same as erasing the keypad, you can download the default values to the keypad. Using CpxxLoad, download the DefaultCP24.ckd or DefaultCP48.ckd file to the keypad. Here are the factory default key values:

Default CP24 key table:

F1	F2	F3	F4
F5	F6	F7	F8
7	8	9	F9
4	5	6	F10
1	2	3	F11
Back	0	Enter	F12

Default CP48 key table:

01 Enter	02 Enter	03 Enter	04 Enter	05 Enter	06 Enter	07 Enter	08 Enter
09 Enter	10 Enter	11 Enter	12 Enter	13 Enter	14 Enter	15 Enter	16 Enter
17 Enter	18 Enter	19 Enter	20 Enter	21 Enter	22 Enter	23 Enter	24 Enter
25 Enter	26 Enter	27 Enter	28 Enter	29 Enter	30 Enter	31 Enter	32 Enter
33 Enter	34 Enter	35 Enter	36 Enter	37 Enter	38 Enter	39 Enter	40 Enter
41 Enter	42 Enter	43 Enter	44 Enter	45 Enter	46 Enter	47 Enter	48 Enter

In addition Key Rollover is set to 2 and the LED is set to show the state of Caps Lock.

Un-Installing and Re-Installing

It's a quick and simple matter to remove, re-install or upgrade MacroMaster. To un-install MacroMaster, click on:

Start >> Programs >> Genovation >> MacroMasterCPxx >> Uninstall MacroMasterCPxx

Or use Add/Remove Programs from within the Control Panel.

The un-installer will NOT remove any macro files you have created. If you are not installing a newer version, you may delete the macro files and directories manually.

If you are installing a newer version (upgrading), your macro files will be saved for you.

The Documents location can be found by clicking on the **Help** button and then selecting **About...** from the menu.




Note: As per Microsoft's requirement, MacroMasterCPxx places the data files in the documents area rather than in the Program Files area.

2: Using MacroMasterCPxx

Running MacroMasterCPxx

To program the ControlPad key codes or change the keypad properties use the MacroMaster application. To begin, click on the following (or similar):

Start >> Programs >> Genovation >> MacroMasterCPxx >> MacroMasterCPxx



The title bar contains the name of the application and the status bar at the bottom shows the name of the file that is opened.


If the file has been changed but not saved, “Modified” appears on the bottom right of the status bar. This will go away once the file is saved or a new file is loaded.

If the file has been changed but not saved, “Modified” appears on the bottom right of the status bar. This will go away once the file is saved or a new file is loaded.


The buttons on the top row access the major functions of the program.



At the center left of the screen is a Virtual CPxx Keypad. It is a series of squares that represent the keys on the actual CPxx keypad hardware. You can choose your CPxx keypad type here.




To the right of this is a grid of rectangles. This is the Key Macro Editor. It holds the data associated with each key on the virtual CPxx keypad.



Every time you select a new virtual CPxx keypad key, a new set of grid cells is available to fill with keyboard data.

The bottom of the screen shows a rendition of a “101-key” PC keyboard. Its purpose is for macro creation and it has additional “keys” such as F13 to F24. Both this virtual one and your real keyboard will play a role in macro creation. And the mouse too.



This Virtual PC Keyboard can be used to place the data into the grid by mouse clicking on the keys shown. You may also type the data in on your actual hardware PC keyboard (light keys only, the shaded keys must be clicked if you need their specific key codes).

So remember, the virtual keypad represents the CPxx and the virtual keyboard represents the PC keyboard. .

Creating and Saving your first CKD file


The file type used by MacroMaster is a .CKD file. CKD stands for **C**ustom **K**ey **D**efinition file. The file is simply a collection of key macros. Its contents are arranged in standard INI file format. To start a new project, click **New** at the top left. This will provide a completely blank template with no keys assigned.

1. Select a key to program. Click on one of the keys on the virtual keypad. Note that whenever you select a new key, the Key Data Editor reflects the key number, for example:

Key Codes for Key 2, Level 1

Each key on the virtual keypad can contain about 220 bytes of macro data.


2. Enter some key data. Try typing in the phrase “hello world” (without the quotes). You should see something like the following.




3. Provide a description. Although it's optional you should consider typing in a short description for your macro. For example:



4. Select repeat mode. If you want the macro to repeat over and over when you hold the keypad key down, click the repeat checkbox:



5. Save the file. Once you are happy with your macro, save the file by clicking on the **Save As** button at the top left. Name the file something appropriate and click **Save**.



Congratulations, you have completed your first macro! It's only one key, but you now understand the basics of macro programming.

The Shaded Keys

MacroMaster's virtual PC keyboard has keys that are standard light gray color and keys that are darker gray. The light gray keys can be used to enter macro data directly by typing on your real PC keyboard (assuming your hardware PC keyboard has the keys).

The dark gray keys can be used to enter macro data only by clicking the virtual keys with the mouse. The dark gray keys on your real PC keyboard retain their original function. For instance, the arrow keys allow you to navigate the cells in the grid.


Correcting Mistakes

If you make a mistake while entering your key macro data, there are several ways to correct it.


- If you want to erase only one cell in the grid, double-click the mouse on that cell. Remember to select the cell at the end of the macro before you begin typing again. The blue box cell always indicates where new data will go.



- If you want to erase only one cell in the grid, use the **Backspace** key on your PC keyboard. Recall that this is a dark gray key so it does not generate a macro entry.
- You can erase the codes in the selected cell by clicking on the **Erase Selected** button.



- For a given macro, if you want to start over, click on the **Erase All** button. This operation only affects the current Level.



Key Codes

The macro you created at the start of this section is very simple. Each square in the black grid contains exactly one byte. You can reveal the underlying codes at any time by checking the box **Reveal Codes** located under the grid.

Reveal Codes: ☒

MacroMaster displays the codes in AT scan code format (see Appendix). The keypad internally uses these codes (as does the PC) since they allow the most flexibility when creating your macros.

Key Codes for Key 1, Level 1

☐ This macro can auto-repeat

Mode: Default (Auto Sense) ▼

Description:

Length of key data = 17 of 220

12	33	f0 12	24	4b	4b	44	29
12	1d	f0 12	44	2d	4b	23	

Reveal Codes: ☒

Erase Selected Erase All

To return to the original (text) view, uncheck the Reveal Codes box.

Geek Mode On!

Although you may not be aware of it, the ControlPad generates (but does not store) three bytes for each of the cells in the grid above. When you press a key, a “make” code is generated. For an h key the ControlPad (or PC keyboard) sends the byte 33 to the PC. The PC interprets this as “h key is pressed”. When you release the h key, the ControlPad (or PC keyboard) sends a “break” code. For the h key this would be the two-byte pair F0 33. The PC interprets this as “h key is released”.

If you press and hold the h key, the ControlPad (or PC keyboard) generates a series of make codes. This is what causes a key to repeat.

Your ControlPad “compresses” standard alphanumeric key data into one byte. This way your h key only takes up one byte instead of three (the 33 alone instead of the 33 make plus the F0 33 break).

Now, some keys on the PC keyboard require more than one byte (the extended keys). These are also compressed by the ControlPad, but generally take only 2 bytes instead of the uncompressed 5 bytes they would normally require. For instance the Enter key on the numeric keypad looks like

this in text mode

Ent(KP)	
---------	--

 and like this is hex mode

e0 5a	
-------	--

. The break code for that key would be E0 F0 5A.


Geek Mode Off!

Modifiers

Modifiers (Shift, Ctrl, Alt and Win) are different again. The ControlPad doesn't compress modifiers since it's required to know when they go down and later when they go back up.

When used with alphanumeric keys to create uppercase letters or symbols (for example), you must create at least three cells:

- The first is the modifier make. When you click on one of the modifier keys, the key “sticks” down. The data entered in the cell has a “Dn” appended to it to indicate that it represents the down (make) code.



- Enter the alphanumeric data you want “modified” (shifted).
- Click on the modifier that is stuck in the down position. This will release the modifier.

As an example, to create “Hello World!” you would use the shift modifier three times. The first to capitalize the H, the second to capitalize the W, and the third to create the exclamation mark on the 1 key.

L Shift Dn	H	L Shift Up	e	l	l	o	Space
L Shift Dn	W	L Shift Up	o	r	l	d	L Shift Dn
!	L Shift Up						

NOTE: Be careful not to leave a modifier in the stuck down position. This can cause your PC to become stuck in the shifted/modified state. It is a common

mistake for ControlPad novices. If you manage to create a stuck key on your PC, try the following steps:

1. Press the same key that is stuck down on your regular PC keyboard. This can cause the PC to release the key. For the modifiers, simply press each of the left and right modifier keys once.
2. If the above fails, try unplugging and re-plugging your keyboard. This will cause the PC to reset its keyboard status.



Always test your macros using the TEST application first.

SEE ALSO:


There are other ways to use modifiers in combination with each other or alone. Refer to the advanced topic, Macro Modes, later in this document.

There are many online resources that describe handy key combinations for various applications. Here is a link to one for Microsoft Windows:

<https://support.microsoft.com/en-us/help/12445/windows-keyboard-shortcuts>


Inserting Delays

The ControlPad can rapidly send a long series of keystrokes to the PC. At times the PC, no matter how fast, will be unable to keep up. To give the PC a breather, you can insert delays between your keystrokes. An example of where this is useful is when launching programs from the Windows Run command. If you wanted to launch Notepad.exe on XP by strictly typing, one could press and

release the Windows key  , followed by r for Run⁴, then notepad.exe and finally Enter to activate the OK button (see the footnote below for Win 7 and later).

Compared to your ControlPad, it may take your PC quite a while to perform some of these steps. Inserting delays will make the operation successful every time.

⁴ In Windows 7 and later you must leave out the “r for Run” and just type notepad.exe then Enter. The Win key is a special key and requires care. Read the Advanced section for more detail.



To the right of MacroMaster's virtual PC keyboard is a Delay button and time length slider. The delay amount is adjustable over a range of 4ms to 500ms (half a second) using the slider. Moving the slider tells you how long the inserted delay will be. The default is 200ms (one fifth of a second). Click the **Delay** button to pause the ControlPad for that amount of time. If you need extremely long delays, click it several times in a row.

For our notepad example above (for an XP machine), the finished macro might look like this:

Key Codes for Key 1, Level 1

☐ This macro can auto-repeat

Mode: **Default (Auto Sense)**

Description: Launch the Notepad application
Length of key data = 24 of 220

L Win Dn	L Win Up	Dly 500ms	r	Dly 500ms	n	o	t
e	p	a	d	.	e	x	e
Enter							

This example was intended to show how to use Delays. As far as launching programs or documents are, there is a later section on Shortcuts which may be the preferred method.


Two-Level Programming (Layers)

On your PC keyboard, the number keys 1 through 9 are also used for symbols !@#\$%^&*(). As you know, these symbols are accessed using the Shift key. Similarly, your ControlPad supports two “levels” or “layers” per key.


There are approximately 220 bytes of storage available for each key on your Controlpad keypad. If you only use Level 1 for a given key, you may use all 220 bytes for that Level 1 macro on that key. If you use Level 2 then the macro space is split in half. In that case both Level 1 and Level 2 can have 110 bytes.

In order to use the second level on your ControlPad, you must first assign an access key (a level shift and/or level toggle key) and you must fill in the data for both levels.

1. Assigning the 2nd level access key. Choose a key on MacroMaster’s virtual keypad by clicking it as normal. Then right-click that key. Select whether you want the level access to be Shift (requires that you hold the shift key down) or Toggle (the level switches back and forth every time you press the toggle key).



2. Fill in the 2nd level data. Click on the **Level 2** tab that is located right above the words **Key Codes for Key 1, Level 1**. The words should change to **Key Codes for Key 1, Level 2**. You now have access to a new grid of 111 bytes for your 2nd level macro.




You may have up to two level shifts and toggles. The keys that perform the level shift/toggle function may also contain macros, but it's not very common.

The Keypad Properties panel section describes how to assign an LED indicator so that you can see which level is active.


NOTE: To use a level shift key, a minimum of 2-key rollover **must** be programmed via the Keypad Properties panel since the shift level key must be pressed and held along with another key to access that key's second level macro. See the Properties panel section for information regarding Key Rollover.

Copy and Paste Key Macros

You can copy a key macro from one key/level to another key level if you need to duplicate or move some macro data. First, left-click on the source key as usual to make it the active key. Make sure to choose the correct level too. Now, right-click on the same key to bring up the key menu. Choose **Copy key macro data** from the menu.



Select a new destination key and level for the copied macro. Right-click to bring up the key menu. This time choose **Paste key macro data**.



The source macro will overwrite the key data at the destination but will not disturb the source key.

Note that you can also edit the CKD files by hand using Notepad if you are so inclined.


Keypad Properties

There are several global ControlPad settings that can be modified to suit your application.



Click on the **Properties** button.

This will open up the Properties panel:



The panel elements:


1. Key Rollover. This parameter controls how many keys may be pressed at the same time and be accepted by the keypad. For most control applications, 1-key rollover is recommended. If the ControlPad is used for higher speed data entry or you are using two levels, then 2-key rollover may be preferable.
 - 1-Key: When one key is held down, the keypad will recognize no other key(s).
 - 2-Key or more: Two (or more) keys pressed and held at the same time will be recognized by the keypad. Keys beyond the rollover number will be ignored. A minimum of two-key rollover is required when using a shift level access key or double size keys.

The ControlPad keypad has diode-per key technology allowing for up to 6 keys down at a time with no ghosting.

2. Inter-Character Pacing. This parameter inserts a short pause between **all** bytes sent to the PC. The range for this parameter is 0ms to 20ms. It has the effect of slowing down the typing slightly in case you are working with a slow PC.
3. LED Function. You may select one of 5 functions for the LED in your ControlPad. The default setting is for the LED to show the state of Caps Lock. You may assign the LED to duplicate one of the PC's internal LED states (Caps Lock, Num Lock or Scroll Lock) or you may assign it to illuminate when the keypads own 2nd level is active (Level Indicator). Finally, you may also control the LED from within a macro or from the Host PC or simply use it for a power indicator or leave it off entirely. The 2nd and 3rd LEDs are CP48 special order options.
4. USB Device Type. This tells the host PC what type of device the ControlPad is. Most users will use the MultiMedia Keyboard. This is a standard keyboard plus things like Volume, Mute, etc. (more info on this later). The Basic Keyboard omits the multimedia keys so it may be better suited to a "dumb" PC (something without a full blown operating system on it). Finally, the third choice adds Mouse functionality if you want to utilize mouse clicks.

Double Size Keys

Genovation sells an accessory kit for those who wish to utilize double size keys.



When programming double size keys it is recommended to program only one of the two keys that are combined into the double size key.

Keycap Labels



Click on the **Key Labels** button

The ControlPad keys have clear lenses that allow for labels may be inserted under the lens to indicate the key function. Several templates are provided for Wordpad, Word, Paint and Excel in the "Keycap Files" folder. Text, images or icons may be inserted in the template. The resulting file can be printed and saved. The labels can then be cut with scissors and placed under the lens caps.

Don't overlap the edge of the key tops with the paper (this can stress the lens cap).

Key Blockers

If you have unused keys you can install a Key Blocker in that position instead of leaving an empty keycap. This gives your keypad a polished look and you can also use the blockers to partition the keypad into functional areas visually.

IMPORTANT: When you install a Key Blocker, your key will be permanently pressed down. It is important for you to make sure that **both layers of a blocked key have no macro data on them** (using




MacroMaster). The keypad is designed to completely ignore keys that have no data assigned to them.

Contact Genovation for an accessory Key Blocker Kit.

Uninstalling/Removing MacroMaster

Before you uninstall the application you should backup and remove any .CKD files or keycap labels you have created. This will allow the uninstaller to completely remove the MacroMaster application and all folders. Once you have done that, click on the following (assumes default installation path):

Start >> Programs >> Genovation >> MacroMasterCPxx >> Uninstall MacroMasterCPxx



Or you can use the Control Panel to uninstall the program.

Customization Is Standard

The ControlPad product line has been designed with customization in mind. Contact our sales or technical support staff for full-custom or semi-custom variations of our products.

3: Advanced Topics

LED Programming


The CP24 and CP48 come standard with one programmable LED installed. By special order, the CP48 can be fitted with 2 additional LEDs.

The LED state can be controlled from within a macro or from a special application running on the Host PC.




Macro LED Control:

To insert an LED state code in a macro, click the LED1 key.




In the pop-up list are the three choices for controlling the LED from within a macro.

If you are using more than one LED state in a given macro you should also insert some delays so that the LED is visible. If you are using separate keys to turn the LED on and off, then no delay is required.



Host LED Control:

~~Controlling the LED from the Host PC over USB will require software on the PC side to control the LED state (on, off or flashing). Some C language demonstration programs are available from~~



Genovation that show how to control the LED from a PC.

Multimedia and More Keys

The ControlPad supports the following multimedia keys.

PS/2	USB	Comment
E0 4D	00B5	Scan Next Track
E0 15	00B6	Scan Previous Track
E0 3B	00B7	Stop
E0 34	00CD	Play/Pause
E0 23	00E2	Mute
E0 32	00E9	Volume Up
E0 21	00EA	Volume Down
E0 50	0183	Media Select
E0 48	018A	Mail
E0 2B	0192	Calculator
E0 40	0194	My Computer
E0 10	0221	Web Search
E0 3A	0223	Web Browser/Home
E0 38	0224	Web Back
E0 30	0225	Web Forward
E0 28	0226	Web Stop
E0 20	0227	Web Refresh
E0 18	022A	Web Favourites
E0 3B	00B7	USB Eject*


* Not all operations are available on all operating systems.

And these keys as well:

PS/2	USB	Comment
0F	67	Keypad =
6D	85	Keypad , (Brazil Keypad .)
51	87	Int'l 1 (Ro)
13	88	Int'l 2 (a: Katakana/Hiragana)
6A	89	Int'l 2 (b: Yen)
64	8A	Int'l 4 (Henkan)
67	8B	Int'l 5 (Muhenkan)
27	8C	Int'l 6 (PC9800 Keypad ,)
63	92	Lang 3 (Katakana)
62	93	Lang 4 (Hiragana)
61	64	Europe 2


Not all operations are available on all operating systems.

In order to insert a one of these keys into a macro, select the key, select the cell and then click on either the **Media...** button or the **More...** button. Click on the desired special key from the list.



Macro Modes

The ControlPad plays back macros for the keys in one of three modes. Every macro can have its own mode and the setting is adjusted via the **Mode** drop down box:



Note that the three modes are Separate Up Codes, Macro Mode and Literal Mode.

The first item on the list, Default (Auto Sense) is not a unique mode in itself. The Default setting actually tells MacroMaster to choose one of the next two modes for you automatically (Separate Up Codes or Macro Mode). Normally MacroMaster will make the correct decision for you, but there are times you may want to override this setting and specify one of the three modes yourself.

If you find that your macro is not operating as you intended, you may have to dig under the hood a little to either select the correct mode and/or modify some of the codes in your macro. The following section describes the three modes in detail.

Modes: Separate Up Codes (v1.13+)

This mode is used to generate combinations of keys or individual keys that may be used in combination with other keys. In this mode your macro supplies the standard code for:

- All modifier key make codes (**only**)
- Alphanumeric make codes only

In this mode the make codes are all played at once on ControlPad key down (and repeats if enabled). On ControlPad key up, the macro is rewound to the beginning and this time the break codes are generated. For musicians **this is like a “chording” style**. If you had a macro containing the letters `t h` and `e`, then it would be realized as: *t make, h make, e make, ...repeat(s)... t break, h break, e break.*


This is not common for the PC because it allows multiple alphanumeric keys to be pressed all at once (which can have its uses, though rare). It works well for true single keys or modifiers or for combinations of modifiers, etc.

If you only have a single key in your macro, this is the best way to implement it. The “Default (Auto Sense)” feature of MacroMaster selects this automatically when it detects a macro that is a single key.

Geek Mode On!


Not technical enough for you yet? The CPxx uses the standard USB keyboard report for widest compatibility. This report allows for up to 6 regular keys to be held down at once in addition to the modifier keys. So you could create a macro that holds these keys all down at once: `abcdef`. As well you could have any combination of Shift, Ctrl and Alt down.

Let's say you created a macro using Separate Up Codes that contains the characters 12345Enter. In this case you would find ALL of these characters repeat (depends somewhat on the PC's OS too). So you would see something like:



You can't see the ENTER key, but because 12345 appears over and over on a separate line, it is obviously working.

Another thing to be careful of is the modifiers. Since the macro synthesizes the up codes when you release the key, you should not include the up codes for the modifiers. Here is an example that repeats the keys !@#\$Enter.



Geek Mode Off!

Modes: Macro

This mode is used to emulate normal typing, such as entering a string of characters. Or more accurately, the typing that a “two-fingered peck and poke” typist would do. In this mode your macro supplies the standard code for:

- All modifier key make and break codes
- Alphanumeric make codes only

When the keypad plays the macro back, the modifier codes are played literally but the alphanumeric codes are “uncompressed” to create make codes followed by break codes. **The alphanumeric codes are played one at a time.** For our

earlier Hello World example the keypad would generate the following keys: *shift make, h make, h break, shift break, e make, e break, etc...*

All of the operations described above happen on the ControlPad key down (and repeats, if enabled). Nothing happens when you release the key on your ControlPad.

The “Default (Auto Sense)” feature of MacroMaster selects this automatically when it detects a macro that has more than a single key.


Modes: Literal

In this mode you know exactly what you want, byte-for-byte. In this mode your macro supplies:

- Everything

The macro is played literally on ControlPad key down (and repeats). Nothing happens on ControlPad key up.

There are two ways to edit the codes literally. The first method is to edit the CKD (INI) file by hand. You will need to look at the key table in the appendix to enter the correct codes. The second method is to use MacroMaster, though it may have some limitations since there is no “hex editor”. The most important tool here is the “Manually Insert a break code” operation. This is selected by clicking on the **More...** key.



As a simple example, here is the literal macro for “Hi” (not including the quotes):

Mode: Literal (Advanced) Length of key data = 9 of 220

L Shift Dn	H	Break	H	L Shift Up	i	Break	i
------------	---	-------	---	------------	---	-------	---

Reveal Codes: ☐

Mode: Literal (Advanced) Length of key data = 9 of 220

12	33	f0	33	f0 12	43	f0	43
----	----	----	----	-------	----	----	----

Reveal Codes: ☒


It is shown as text on top and again in hex codes on bottom. **Remember that all of the break codes must be present too.** So for each key you will have make code, F0, make code. The CKD file entry for this macro looks like this:

Level_1_Codes = 1233f033f01243f043

Mouse Programming


The five mouse buttons behave very similar to individual PC keys, but not exactly. You may click a mouse button, hold a mouse button down or double-click a mouse button, but you wouldn't normally repeat a mouse click over and over like you would a keypress, gaming applications aside. Here are some tips for performing the various mouse button actions in a macro.

First, locate the 5 mouse buttons (and scroll wheel). Your mouse may be different.




1. Left Button
2. Middle Button (press the wheel)
3. Right Button
4. Scroll Wheel action up
5. Scroll Wheel action down
6. Reverse Button (also called X Button 1)
7. Forward Button (also called X Button 2)


For testing the mouse you may use the Genovation KeyTest utility, but make sure to enable Mouse Clicks. Also, **make sure the mouse is hovering over the dark area of the KeyTest form.**



To insert a mouse action using MacroMaster, use the pop-up menu associated with the Mouse button located in the MacroMaster application. It is found above the numeric keypad.




Important: The Genovation keypad itself must be set to emulate a mouse as well as a keyboard. This is set using the Properties Panel.




Single Click

For a single click without any repeated clicks, select a mouse button from the Mouse pop-up menu. Use one of the options from the top part of the menu called, “Button Down/Click”.



Leave the Macro Mode on the “Default” setting and make sure the “auto-repeat” box is clear (not checked). In this way you will get exactly one mouse click when the keypad button is pressed. Nothing happens when you release the keypad key.



After you Save, Download and Test this macro, you will see that when you press the keypad key, the mouse button is pressed and immediately released, even before you take your finger off of the key.

AT Code	Key	Comments	/	Virtual Key
(e0 61)	--	L Button Down		
(e0 f0 61)	--	L Button Up		


Of course, if you press the keypad key twice quickly, you will get the equivalent of a double-click. There is a better way to automate a double-click, and that will be shown later.

Repeating Clicks

Although very rare, it may be useful to have a rapid series of mouse clicks. It should be noted that the operating system and/or running application may interpret this as a mix of single and double-clicks.


To configure this, your best bet is to use the “Default” macro mode and simply check the box titled “This macro can auto-repeat”.

There is an alternative way of achieving this and that is to select the “Macro (Advanced)” macro mode and again check the auto-repeat box.



Double-Click

A double-click needs to emulate pressing and releasing a given mouse button twice. Not three, four, five or more. You can do this by performing the steps in Single-Click above, then add a Delay, then add another Single-Click. The Delay pauses the keypad macro briefly in-between the clicks and this tells the computer that the user is double-clicking. You can set the Delay value using the Value slider on the main form and any value should theoretically work.



For some applications faster may be better. The Delay amount can be set using the slider. Its range is 4ms (0.004 seconds) to 500ms (0.5 seconds).

Note: The other use of the slider is for setting the amount of movement a mouse makes when mouse moves are included in a macro.

Keep the auto-repeats turned off. The final result should look something like below. Again, everything happens when the keypad key is pressed. Nothing happens when the keypad key is released.

Key Codes for Key 9, Level 1

☐ This macro can auto-repeat

Mode: Default (Auto Sense)

L Click	Delay 200ms	L Click	
---------	-------------	---------	--

```

(e0 61)      --      L Button Down
(e0 f0 61)   --      L Button Up
(e0 61 x2)   --      L Button Dbl-click
(e0 f0 61)   --      L Button Up
  
```


Press and Hold (for Drag)

If you want to simulate pressing a mouse button down, and releasing it at a later time, then the Macro Mode needs to be set appropriately. By Choosing Separate Up Codes, the mouse button will go down on keypad keypress and remain in the pressed position until the associated keypad key is released.

Key Codes for Key 12, Level 1

☒ This macro can auto-repeat

Mode: Separate Up Codes

L Click

Demonstration

An example macro file is available (MouseClicks.ckd) with all of these operations includes and a few extras that show mouse movements and scroll wheel usage as well. Here is a map of the operations, shown on a CP48.

	Left Mouse Button	Right Mouse Button	Center Mouse Button	Reverse Mouse Button	Forward Mouse Button				
Press and Hold									Wheel Forward
Click							Up		Wheel Reverse
Double Click						Left	Down	Right	Mouse Moves

Mouse Customization

There are many ways to customize the mouse settings using built-in OS configuration and/or 3rd party applications. One of the more popular 3rd party mouse control programs is called “X-Button Mouse Control”. It has a wide variety of customizations for mouse operation and control.



X-Mouse Button Control:

<https://www.howtogeek.com/howto/14400/use-those-extra-mouse-buttons-to-increase-efficiency/>

Shortcuts

Objective: Access an application or document using a keypress combination.

If you place a shortcut to a document or application on the Desktop⁵, then you can access that item quickly. You can also add a hot-key combination to it so that it can be launched via a keypress. Here is an example desktop shortcut and the properties for it. A shortcut's properties can be accessed by right-clicking it.



⁵ The functionality in this section will work for Shortcuts placed on the Desktop, on the Start menu, or in the Windows\\Start Menu\\Programs folder. Consult the Microsoft documentation for more details.

Note the area marked in red. If you click your mouse here you can then press a letter on your keyboard to set a hot-key combination. So if you had pressed the letter N, you would see.

Shortcut key:

Then in order to activate this shortcut, you would use the Ctrl + Alt + N key combination (if the item on the desktop is a document or data file, then the application associated with it will launch).

MacroMaster has a “wizard” built-in that creates a shortcut. Click on the Shortcut item on the right side of the main menu.



This opens up the form for quickly creating a shortcut:

A screenshot of the 'Shortcut Wizard' dialog box. The title bar reads 'Shortcut Wizard'. The main area has a dark blue background with two icons: 'MyShortcut' (a black device) and 'To-Do List Shortcut' (a document icon). Below this, a text box contains instructions: 'Use this Shortcut Wizard to create a Shortcut on the Desktop to a CKD file for downloading or any other file/application for launching from a hot-key:' followed by a numbered list: 1. Select the target CKD (or other) file that the shortcut will activate. 2. Fill in the Comment (the hint that you see when you hover the mouse over it). 3. Set up a hot key to launch the shortcut (press and release a letter key). 4. Click on Create. Below the instructions are three input fields: 'Target File:' with a 'Choose Target File...' button, 'Comment:' with the placeholder text 'My shortcut comment (hint)', and 'Shortcut key:' with a placeholder '(Press a key in this box for shortcut)'. At the bottom are 'Create' and 'Cancel' buttons.

To create the shortcut, follow these steps. In this example we will create a shortcut to load a CKD file, but it could be any application or document (that has an application assigned to its type) located anywhere on the PC:

1. Click on **Choose Target File** and navigate to the CKD file that you would like to download to the keypad. Select the CKD file and click the Open button. The file will show up in the field above “Choose Target File”.
2. Type a short comment into the **Comment** field. This information will appear when you hover your mouse over the shortcut.
3. Place the cursor in the **Shortcut key** field. Press and release a letter key (for example) to assign a hot-key combination to the shortcut. The field will modify itself to show you what the combination to activate the shortcut is. Make a mental note of this key combination.
4. Click on **Create**. You should now have a shortcut to your specified CKD file on the desktop.
5. Press the hot-key combination (something like Ctrl + Alt+ K). The file downloader should launch and download the CKD file to your keypad. After the download is complete the ControlPad will reboot so wait a few moments while the PC re-initializes the connection.

Just to clarify, the shortcut can point to pretty much anything, anywhere. However, in order to use a hot-key combination to activate the shortcut, the shortcut needs to be on the Desktop (or the Start menu, or in the Windows\Start Menu\Programs folder).

You can modify the shortcut by finding it on the desktop and right-clicking on it.

This brings us to the second objective; let's put this on a programmable key!

Rapid Reconfiguration

Objective: Use an existing shortcut to reconfigure the ControlPad.


The previous section used a CKD file rather than a Word document for a reason. That reason is that it is the first step in creating a self-reconfiguring keypad setup.

It should be obvious by now, that clicking on the shortcut created earlier will download a CKD file to the keypad. And you saw how to assign a hot-key

combination to it. So the next logical step is to store that hot-key combination in a key macro so that a key on the keypad can reprogram the keypad! Right?

The implementation is actually pretty simple. All you have to do is reserve one key on your keypad to launch the other version of the keypad. So it's like having two "keypads", selectable by key. Each of these "keypads" can have the full two layers if needed, and you can extend this technique as much as you like.


So, all you need to do is add the hot-key(s) for shortcut to a CKD file, like so:



Then, when this CKD is loaded onto the keypad, it can reconfigure the keypad to be the "other" keypad, the one the above stuff refers to. That is, when you press Key1, Level 1 in this case.


Downloading via PRG/TMode (TMode⁶ Models Only)

In the unlikely event that you have trouble downloading to your keypad, there is an alternate method of downloading available. Run CPxxLoad. Click on the little down-arrow beside Options. Then select **Download CKD via PRG/TMode**. This mode requires you to operate the rear panel switch during downloads.



⁶ Keypads may contain the firmware for PRG/TMode or Flash Drive programming, but not both.


When downloading to the keypad **you will need to move the rear panel switch** to the **PRG** position⁷. CPxxLoad will remember your preference and will guide you when you download a CKD file.



Downloading via Drag n Drop (Flash Drive Models Only)


If you have already created your keypad definition file, you can use File Copy or Drag-n-Drop to send it to your keypad. This technique requires using the rear panel switch to place the keypad in “USB Flash Drive” configuration⁸.

This may be done manually or with the guided assistance of CPxxLoad.



⁷ The second switch position may be identified with either a “thumb drive” symbol or PRG. The first time you use the new mode Windows may install drivers for it.

⁸ Do not copy any other files to the keypad except .BIN files.



Move the rear panel switch from **Keypad** operation to **USB Flash Drive Mode**. You will see the light flicker and eventually turn **solid red**. The first time you do this your computer will display the new USB device balloon. Once the LED becomes solid red, you should have a new disk drive called CONTROLPAD available to you. You can copy your **.BIN** file from your Macro Files directory to the CONTROLPAD drive. Note that it must be the .BIN file, not the .CKD file.

Once the file has been copied over, move the switch back to the Keypad position. It may take a while for the keypad to process the .BIN file, and as it does so you may see the LED flickering blue/red. Once processing is complete, the keypad will resume normal operation with your new definitions installed.


Reflashing the Firmware

The operating system code in the CPxx can be updated over USB starting in either the standard (legacy) mode or the PRG/TMode configuration. Either of these two modes is capable of launching the bootloader inside the CPxx to do the actual update.


Begin by launching the downloader utility program (CPxxLoad.exe). Click on

Start >> Programs >> Genovation >> MacroMasterCPxx >> CPxxLoad


The downloader opens. With the keypad connected in either mode, click on the Connect button. You should see some information about your keypad.




USB Standard Mode is shown above, USB TMode below.




Click on **Open File**. Change the **File Type** to Firmware Upgrade (*.upg).




Navigate to the location of your UPG firmware upgrade file. Select the file and click on **OK**. The file will be loaded.




Click on **Download**. First, the keypad will need to be switched over to “bootloader” mode. Click on **Yes**.




After a few moments (please wait!) more information about the keypad is retrieved.




Finally you will need to click on OK and then **Download** again.



This process will take some time. Do not interrupt it.



When it is finished you will see the **SUCCESS** message.



After the keypad reboots you may begin using it. You may find it necessary to re-download your CKD file after a firmware upgrade.

4: Technical Specifications

	CP24	CP48	KB170
Number of Keys	24 relegendable mounted on an industrial strength metal sub panel.	48 relegendable mounted on an industrial strength metal sub panel.	66 relegendable mounted on an industrial strength metal sub panel.
Key Type	Gold plated industrial quality Cherry MX key switches. Travel 3.5 mm (0.14"). Operating force is 0.686N (79gf). Life 5 X 10 ⁷ Cycles.	Gold plated industrial quality Cherry MX key switches. Travel 3.5 mm (0.14"). Operating force is 0.686N (79gf). Life 5 X 10 ⁷ Cycles.	Gold plated industrial quality Cherry MX key switches. Travel 3.5 mm (0.14"). Operating force is 0.686N (79gf). Life 5 X 10 ⁷ Cycles.
USB Port	USB 1.0, 1.1, 2.0 and 3.0 compatible. HID keyboard with optional multimedia and/or mouse.	USB 1.0, 1.1, 2.0 and 3.0 compatible. HID keyboard with optional multimedia and/or mouse.	USB 1.0, 1.1, 2.0 and 3.0 compatible. HID keyboard with optional multimedia and/or mouse.
USB Hub	No	No	Yes – One free port available
PS/2 Keyboard Port	PS/2 version available as special order only.	No	No
RS232 Serial Port	USB virtual serial and true DB9 RS232 versions are available.	USB virtual serial and true DB9 RS232 versions are available.	n/a
Power	Bus-powered. No external power supply required.	Bus-powered. No external power supply required.	Bus-powered. No external power supply required.
Number of programmable LEDs	1 (dual color)	1 (dual color) 2 (single color) - optional	1 (dual color)
LED Modes	CapsLock, NumLock, Level, Host/Macro, ScrollLock, Power	CapsLock, NumLock, Level, Host/Macro, ScrollLock, Power	CapsLock, NumLock, Level, Host/Macro, ScrollLock, Power
Temperature	0C to 70C (32F to 158F)	0C to 70C (32F to 158F)	0C to 70C (32F to 158F)
Dimensions	TBD	TBD	TBD
Weight	TBD lbs. shipping weight	TBD lbs. shipping weight	TBD lbs. shipping weight
Macro Storage	Two levels, 110 bytes per level, 220 bytes per key	Two levels, 110 bytes per level, 220 bytes per key	Two levels, 110 bytes per level, 220 bytes per key
Level shift keys	0, 1 or 2 assignable.	0, 1 or 2 assignable.	0, 1 or 2 assignable.
Level toggle keys	0, 1 or 2 assignable.	0, 1 or 2 assignable.	0, 1 or 2 assignable.

Rollover**	1 to 6**	1 to 6**	1 to 6**
Storage Type	High reliability Flash	High reliability EEPROM	High reliability EEPROM
Endurance	100,000 write cycles	100,000 write cycles	100,000 write cycles
Data Retention	100 years	100 years	100 years
Program Method	MacroMasterCPxx application	MacroMasterCPxx application	MacroMasterKBxx application
Driver Requirement	None (uses OS native drivers)	None (uses OS native drivers)	None (uses OS native drivers)
MacroMaster OS	Microsoft Windows (Win7 or newer)	Microsoft Windows (Win7 or newer)	Microsoft Windows (Win7 or newer)
Operating Systems, unit in use	USB hardware supports all OS types (Win, Mac, Linux)	USB hardware supports all OS types (Win, Mac, Linux)	USB hardware supports all OS types (Win, Mac, Linux)
Will boot PC in standalone mode	Yes	Yes	Yes

** The CPxx/KBxx itself has n-key rollover and you can hold as many keys down as you like (as set by the Properties panel). The USB keyboard report supports up to 6 keys down plus any combination of modifiers down.

A: Appendix

Scan Code Table

All values are hexadecimal AT (PS/2) scan codes.

Function	Make Code(s)	Break Codes
F9	01	F0 01
F5	03	F0 03
F3	04	F0 04
F1	05	F0 05
F2	06	F0 06
F12	07	F0 07
F13 (new)	08	F0 08
F10	09	F0 09
F8	0A	F0 0A
F6	0B	F0 0B
F4	0C	F0 0C
TAB	0D	F0 0D
` ~	0E	F0 0E
Keypad =	0F	F0 0F
Function	Make Code(s)	Break Codes
F14 (new)	10	F0 10
L Alt	11	F0 11
L Shift	12	F0 12
Int'l 2 (a)	13	F0 13
L Ctrl	14	F0 14
q Q	15	F0 15
1 !	16	F0 16
F15 (new)	18	F0 18
z Z	1A	F0 1A
s S	1B	F0 1B
a A	1C	F0 1C
w W	1D	F0 1D
2 @	1E	F0 1E
Function	Make Code(s)	Break Codes
F16	20	F0 20
c C	21	F0 21
x X	22	F0 22
d D	23	F0 23
e E	24	F0 24
4 \$	25	F0 25
3 #	26	F0 26

Int'l 6	27	F0 27
F17	28	F0 28
Space	29	F0 29
v V	2A	F0 2A
f F	2B	F0 2B
t T	2C	F0 2C
r R	2D	F0 2D
5 %	2E	F0 2E
F13 (old)	2F	F0 2F
Function	Make Code(s)	Break Codes
F18	30	F0 30
n N	31	F0 31
b B	32	F0 32
h H	33	F0 33
g G	34	F0 34
y Y	35	F0 35
6 ^	36	F0 36
F14 (old)	37	F0 37
F19	38	F0 38
m M	3A	F0 3A
j J	3B	F0 3B
u U	3C	F0 3C
7 &	3D	F0 3D
8 *	3E	F0 3E
F15 (old)	3F	F0 3F
Function	Make Code(s)	Break Codes
F20	40	F0 40
, <	41	F0 41
k K	42	F0 42
i I	43	F0 43
o O	44	F0 44
0)	45	F0 45
9 (46	F0 46
F21	48	F0 48
. >	49	F0 49
/ ?	4A	F0 4A
l L	4B	F0 4B
; :	4C	F0 4C
p P	4D	F0 4D
- _	4E	F0 4E
Function	Make Code(s)	Break Codes
F22	50	F0 50
Int'l 1	51	F0 51
‘ “	52	F0 52
[{	54	F0 54

= +	55	F0 55
F23	57	F0 57
Caps Lock	58	F0 58
R Shift	59	F0 59
Enter	5A	F0 5A
] }	5B	F0 5B
\	5D	F0 5D
F24	5F	F0 5F
Function	Make Code(s)	Break Codes
Europe 2	61	F0 61
Lang 4	62	F0 62
Lang 3	63	F0 63
Int'l 4	64	F0 64
Backspace	66	F0 66
Int'l 5	67	F0 67
Keypad 1	69	F0 69
Int'l 2 (b)	6A	F0 6A
Keypad 4	6B	F0 6B
Keypad 7	6C	F0 6C
Keypad ,	6D	F0 6D
Function	Make Code(s)	Break Codes
Keypad 0	70	F0 70
Keypad .	71	F0 71
Keypad 2	72	F0 72
Keypad 5	73	F0 73
Keypad 6	74	F0 74
Keypad 8	75	F0 75
Escape	76	F0 76
Num Lock	77	F0 77
F11	78	F0 78
Keypad +	79	F0 79
Keypad 3	7A	F0 7A
Keypad -	7B	F0 7B
Keypad *	7C	F0 7C
Keypad 9	7D	F0 7D
Scroll Lock	7E	F0 7E
Function	Make Code(s)	Break Codes
F7	83	F0 83
Function	Make Code(s)	Break Codes
R Alt	E0 11	E0 F0 11
R Ctrl	E0 14	E0 F0 14
L Win	E0 1F	E0 F0 1F
R Win	E0 27	E0 F0 27
App	E0 2F	E0 F0 2F
Power	E0 37	E0 F0 37

Keypad /	E0 4A	E0 F0 4A
Keypad Enter	E0 5A	E0 F0 5A
Wake	E0 5E	E0 F0 5E
End	E0 69	E0 F0 69
Left	E0 6B	E0 F0 6B
Home	E0 6C	E0 F0 6C
Insert	E0 70	E0 F0 70
Delete	E0 71	E0 F0 71
Down	E0 72	E0 F0 72
Right	E0 74	E0 F0 74
Up	E0 75	E0 F0 75
Page Down	E0 7A	E0 F0 7A
Page Up	E0 7D	E0 F0 7D

Media Function	Make Code(s)	Break Codes
Search	E0 10	E0 F0 10
Prev Track	E0 15	E0 F0 15
WWW Favorites	E0 18	E0 F0 18
Eject (mac)	E0 1A	E0 F0 1A
WWW Refresh	E0 20	E0 F0 20
Volume Down	E0 21	E0 F0 21
Mute	E0 23	E0 F0 23
WWW Stop	E0 28	E0 F0 28
App 1 (Calc)	E0 2B	E0 F0 2B
WWW Forward	E0 30	E0 F0 30
Volume Up	E0 32	E0 F0 32
Play/Pause	E0 34	E0 F0 34
WWW Back	E0 38	E0 F0 38
WWW Home	E0 3A	E0 F0 3A
Stop	E0 3B	E0 F0 3B
App 2 (My PC)	E0 40	E0 F0 40
Mail	E0 48	E0 F0 48
Next Track	E0 4D	E0 F0 4D
Media Select	E0 50	E0 F0 50

Pause/Break, PrintScreen/SysRq and Mouse operations use custom codes internally and are fully supported over USB.

Additional information can be found in “translate.pdf” (courtesy of Microsoft) and “Hut1_12.pdf” (courtesy of USB.org).